

Tel: 866-777-6060

Fax: 866-777-6383



PWR-FLOT

NPF07 POLYPROPYLENE PUMP CLAMPED PWR-FLO AIR DISTRIBUTION SYSTEM



AIR-OPERATED O DOUBLE DIAPHRAGM O PUMPS



Springer Pumps, LLC

Website: www.springerpumps.com Int'l: +001 267 404 2910

NOMAD

CAUTIONS - READ FIRST



CAUTION: Do not apply compressed air to the exhaust port – pump will not function.



CAUTION: Do not over-lubricate air supply – excess lubrication will reduce pump performance. Pump is pre-lubed.



TEMPERATURE LIMITS:

Neoprene -17.7°C to 93.3°C 0°F to 200°F -12.2°C to 82.2°C Buna-N 10°F to 180°F -15.1°C to 137.8°C -60°F to 280°F EPDM NOTE: Not all materials are available for all models. Refer to Section 2 for material options for your pump.



CAUTION: Check temperature limits for all wetted components. Example: Viton® has a maximum limit of 176.7°C (350°F) but polypropylene has a maximum limit of only 79°C (175°F).



CAUTION: Maximum temperature limit are based upon mechanical stress only. Certain chemicals will significantly reduce maximum safe operating temperatures.



WARNING: Prevention of static parking – if static sparking occurs, fire or explosion could result. Pump, valves, and containers must be grounded to a proper grounding point when handling flammable fluids and whenever discharge of static electricity is a hazard.



CAUTION: Do not exceed 8.6 bar (125psig) air supply pressure.



CAUTION: The process fluid and cleaning fluids must be chemically compatible with all wetted pump components.



CAUTION: Do not exceed 82°C (180°F) air inlet temperature.



CAUTION: Pumps should be thoroughly flushed before installing into process lines.



CAUTION: Always wear safety glasses when operating pump. If diaphragm rupture occurs, material being pumped may be forced out air exhaust.



CAUTION: Before any maintenance or repair is attempted, the compressed air line to the pump should be disconnected and all air pressure allowed to bleed from pump. Disconnect all intake, discharge and air lines. Drain the pump by turning it upside down and allowing any fluid to flow into a suitable container.



CAUTION: Blow out air line for 10 to 20 seconds before attaching to pump to make sure all pipeline debris is clear. Use an in-line air filter. A 5µ (micron) air filter is recommended.

NOTE: When installing PTFE diaphragms, it is important to tighten outer pistons simultaneously (turning in opposite directions) to ensure a tight fit. (See torque specifications.)

NOTE: Before starting disassembly, mark a line from each liquid chamber to its corresponding air chamber. This line will assist in proper alignment during reassembly.




Springer Pumps, LLC

CAUTION: Tighten all hardware prior to installation.

How It Works - Pump



The NOMAD diaphragm pump is an air-operated, positive displacement, self-priming pump. These drawings show flow pattern through the pump upon its initial stroke. It is assumed the pump has no fluid in it prior to its initial stroke.



1. Air Chamber

The air chamber is the chamber that houses the air which powers the diaphragms.

2. Air Distribution System

Tel: 866-777-6060

Fax: 866-777-6383

The air distribution system is the heart of the pump. The air distribution system is the mechanism that shifts the pump in order to create suction and discharge strokes.

3. Lock Nut (Outer Diaphragm Piston)

The outer diaphragm pistons provide a means to connect the diaphragms to the reciprocating common shaft and to seal the liquid side from the air side of the diaphragm.

4. Holding plate (Inner Diaphragm Piston)

The inner piston is located on the air side of the pump and does not come into contact with the process fluid.

5. Check Valve Ball

NOMAD air-operated pumps use suction and discharge check valves to produce directional flow of process fluid in the liquid chamber. The check valve balls seal and release on the check valve seats allowing for discharge and suction of process fluid to occur.

6. Check Valve Seat

The removable seats provide the ball valves a site to check.

7. Discharge Manifold

Process fluid exits the pump from the discharge port located on the discharge manifold at the top of the pump.

8. Liquid Chamber

The liquid chamber is filled with the process fluid during the suction stroke and is emptied during the discharge stroke. It is separated from the compressed air by the diaphragms.

9. Diaphragm

The diaphragm membrane provides for separation of the process fluid and the compressed air power source. To perform adequately, diaphragms should be of sufficient thickness and of appropriate material to prevent degradation or permeation in specific process fluid applications. TABLA offers a variety of diaphragm materials for your specific application requirements.

10. Inlet Manifold

Process fluid enters the pump from the intake port located on the inlet manifold at the bottom of the pump.



N O M A D Suggested Operation & Maintenance

Troubleshooting

Pump will not run or runs slowly.

- 1. Ensure that the air inlet pressure is at least 0.4 Bar (5 psig) above start up pressure and that the differential pressure (the difference between air inlet and liquid discharge pressures) is not less than 0.7 Bar (10 psig).
- 2. Check air inlet filter for debris
- 3. Check for extreme air leakage (blow by) which would indicate worn seals/bores in the air valve.
- 4. Disassemble pump and check for obstructions in the air passageway.
- 5. Check for sticking ball check valves. If material being pumped is not compatible with pump, elastomer, swelling may occur. Replace ball check valves and seals with proper elastomers. Also, as the check valve balls wear out, they become smaller and can become stuck in the seats. In this case, replace balls and seats.
- 6. Check for broken inner piston which will cause the air valve spool to be unable to shift.
- 7. Remove plug from pilot spool exhaust.

Pump runs but little or no product flows.

- 1. Check for pump cavitation; slow pump speed down to allow thick material to flow into liquid chambers.
- 2. Verify that vacuum required to lift is not greater than the vapor pressure of the material being pumped (cavitation).
- 3. Check for sticking ball valves. If material being pumped is not compatible with pump elastomers, swelling may occur. Replace ball check valves and seats with proper elastomers. Also, as the check valve balls wear out, they become smaller and can become stuck in the seats. In this case, replace balls and seats.

Pump air valve freezes.

1. Check for excessive moisture in compressed air. Either install a dryer or hot air generator for compressed air. Alternatively, a coalescing filter may be used to remove the water from the compressed air in some applications.

Air bubbles in pump discharge.

- 1. Check for ruptured diaphragm.
- 2. Check tightness of outer pistons.
- 3. Check tightness of fasteners and integrity of o-rings and seals, especially at intake manifold.
- 4. Ensure pipe connections are airtight

Product comes out air exhaust.

- 1. Check for diaphragm rupture.
- 2. Check tightness of outer pistons to shaft.

Tel: 866-777-6060 Fax: 866-777-6383

Suggested Installation



INSTALLATION:

- Suction pipe equal to/greater than pump diameter (same for discharge)
- Tighten all fasteners before use
- Suction connection should be non-collapsible

AIR SUPPLY:

- Air line size must be large enough to create desired volume (see performance curve section)
- Do not exceed 8.6 BAR (125 PSIG)
- For best results, use 5 micron air filter
- Use lubricator with 5 wt. oil

Tel: 866-777-6060

Fax: 866-777-6383

PIPING:


- Remove as many turns/elbows as possible
- Piping should be supported
- Flexible hose will avoid stress on pump fitting
- Gate Valve should be used in applications involving flooded suction
- In positive suction head conditions, limit inlet pressure to 0.5 - 0.7 BAR (7 - 10 PSI).
 Premature diaphragm failure will take place above the parameters.

ALL NOMAD PUMPS ARE CAPABLE OF PASSING SOLIDS. A STRAINER SHOULD BE USED ON THE PUMP INTAKE TO ENSURE THAT THE PUMP'S RATED SOLIDS CAPACITY IS NOT EXCEEDED.

CAUTION: DO NOT EXCEED 8.6 BAR (125 PSIG) AIR SUPPLY PRESSURE.



Suggested Installation



NOTE: In the event of a power failure, the shut off valve should be closed, if the restarting of the pump is not desirable once power is regained.

SUCTION

AIR OPERATED PUMPS: To stop the pump from operating in an emergency situation, simply shut off valve (user supplied) installed

in the air supply line. A properly functioning valve will stop the air supply to the pump, therefore stopping output. The shut off valve should be located far enough away from the pumping equipment such that it can be reached safely in an emergency situation.

FOOTPAD

Tel: 866-777-6060

Fax: 866-777-6383

How It Works - Pump



| ı | | | 1 2 | _ | 3 4 5 6 | | 7 8 | 9 | 10 | 1 | 12 | 13 | | _ | |
|----|-------------------------|-----|------------------|---|-----------------|-----|------------------------------|-------|------------------|-------|-----------|----|-------------|----|------|
| 1 | Air Distribution System | 7 | Liquid Port Size | 3 | Wetted Parts | 7,8 | Diaphragms & Valve Balls | 9 | Valve Seats | 11 | Fittings | 12 | Connections | 13 | ATEX |
| N | Nomad | 07 | 07mm/.25" | A | Aluminum | BN | Buna - N/ Nitrile | A | Aluminum | N | NPT | (| Clamped | 12 | HILA |
| Ī | Trans-Flo | 15 | 15mm/.5" | W | Ductile | ND | Nordel/EPDM | S | Stainless Steel | В | BSP | В | Bolted | | |
| TG | Gold | 25 | 25mm/1" | S | Stainless Steel | NE | Neoprene | BN | Buna - N/Nitrile | TC | Tri-Clamp | | | | |
| PF | Pwr-Flo | 40 | 40mm/1.5" | Р | Polypropylene | TF | PTFE (with Neoprene back-up) | NE | Neoprene | FL | Flanged | | | | |
| DF | Dura-Flo | 50 | 50mm/2" | 4 | Air Chambers | VT | Viton/FKM | ND | Nordel/EPDM | | | • | | | |
| | • | 80 | 80mm/3" | A | Aluminum | FG | Hytrel® | VT | Viton | | | | | | |
| | | 100 | 100mm/4" | W | Ductile | SN | Santoprene® | SP | Santoprene | | | | | | |
| | | | | S | Stainless Steel | SNF | Santoprene® - UFI | FG | Hytrel | | | | | | |
| | | | | W | Mild Steel | TFF | PTFE - UFI | Р | Polypropylene | | | | | | |
| | | | | Р | Polypropylene | TGN | Garlock® - NEO BACKED | K | Kynar | | | | | | |
| | | | | 5 | Center Block | TGE | Garlock® - EPDM BACKED | PU | Polyurethane | | | | | | |
| | | | | A | Aluminum | TGV | Garlock® - Viton BACKED | MTF | Mild Steel | | | | | | |
| | | | | S | Stainless Steel | PU | Polyurethane | 10 | 0-Ring | | | | | | |
| | | | | Р | Polypropylene | FGF | Hytrel UFI | BN | Buna - N/Nitrile | | | | | | |
| | | | | 6 | Air Valve | PUF | Polyurethane UFI | NE | Neoprene | | | | | | |
| | | | | В | Brass | | | ND | Nordel/EPDM | | | | | | |
| | | | | Р | Polypropylene | | | VT | Viton | | | | | | |
| | | | | A | Aluminum | | | TF | PTFE | | | | | | |
| | | | | S | Stainless Steel | | | PU | Polyurethane | | | | | | |
| | | | | | | | | SN | Santoprene | | | | | | |
| | | | | | | | | PTV | Viton Encap. | | | | | | |
| | | | | | | | | | 5.1 2.100 | | | | | | |

NTG 50 / AAAB / TF / TF / ATF / N / C / X

| | | ' | | 1 2 | • | 3 4 5 6 | | 7 8 | 9 | 10 1 | - - 1 | 12 | 13 | | | |
|---|----|-------------------------|----|------------------|---|--------------|-----|--------------------------|---------|-------------|-----------------|----------|----|-------------|----|------|
| | Г | | Т | | | | | | \perp | | \neg | | 느 | | | |
| , | 1 | Air Distribution System | 2 | Liquid Port Size | 3 | Wetted Parts | 7,8 | Diaphragms & Valve Balls | 9 | Valve Seats | 11 | Fittings | 12 | Connections | 13 | ATEX |
| | N | Nomad | 50 | 50mm/2" | Α | Aluminum | TF | PTFE (with Buna back-up) | A | Aluminum | N | NPT | C | Clamped | | |
| | T | Trans-Flo | | | 4 | Air Chambers | | | 10 | 0-Ring | | | | | | |
| Ī | ſĞ | Gold | | | A | Aluminum | | | TF | PTFE | | | | | | |
| F | PF | Pwr-Flo | | | 5 | Center Block | | | | | | | | | | |
| 0 |)F | Dura-Flo | | | A | Aluminum | | | | | | | | | | |
| | | | | | 6 | Air Valve | | | | | | | | | | |
| | | | | | В | Brass | | | | | | | | | | |


Tel: 866-777-6060


Fax: 866-777-6383



Dimensional Drawings

NPF07 POLY CLAMPED PTFE-FITTED





| ITEM | METRIC (mm) | STANDARD (inch) |
|------|-------------|-----------------|
| А | 145 | 5.7 |
| В | 25 | 1.0 |
| С | 94 | 3.7 |
| D | 140 | 5.5 |
| E | 163 | 6.4 |
| F | 56 | 2.2 |
| G | 30 | 1.2 |
| Н | 30 | 1.2 |
| J | 114 | 4.5 |
| K | 61 | 2.4 |
| L | 74 | 2.9 |
| М | 53 | 2.1 |
| N | 64 | 2.5 |
| Р | Ø5 | Ø.2 |

Tel: 866-777-6060 Fax: 866-777-6383

Performance



NPF07 POLY CLAMPED RUBBER-FITTED


Est. Ship Weight.... Polypropylene 1.4 kg (3 lb)

| Air InletInlet | , , |
|-------------------------------|-------------------------------------|
| Outlet | , , |
| Suction Lift | 2.74 m Dry (9') 9.45 m Wet (31') |
| Disp. Per Stroke ¹ | , , |
| Max. Flow Rate | |
| | |

¹Displacement per stroke was calculated at 4.8 bar (70 psig) air inlet pressure against a 2 bar (30 psig) head pressure.

Example: To pump 7.6 lpm (2 gpm) against a discharge pressure head of 2 bar (30 psig) requires 4.1 bar (60 psig) and 2.0 Nm³/h (1.2 scfm) air consumption. (See dot on chart.)

Caution: Do not exceed 8.6 bar (125 psig) air supply pressure.



Flow rates indicated on chart were determined by pumping water.

For optimum life and performance, pumps should be specified so that daily operation parameters will fall in the center of the pump's performance curve.

NPF07 POLY CLAMPED TPE-FITTED


Est. Ship Weight....Polypropylene 1.4 kg (3 lb)

| Air Inlet | 3 mm (1/8") |
|-------------------------------|--------------------|
| Inlet | 6 mm (1/4") |
| Outlet | 6 mm (1/4") |
| Suction Lift | 3.05 m Dry (10') |
| | 8.84 m Wet (29') |
| Disp. Per Stroke ¹ | 0.02 L (0.005 gal) |
| Max. Flow Rate | 18.1 lpm (4.8 gpm) |
| Max. Size Solids | 0.4 mm (1/64") |

¹Displacement per stroke was calculated at 4.8 bar (70 psig) air inlet pressure against a 2 bar (30 psig) head pressure.

Example: To pump 7.6 lpm (2 gpm) against a discharge pressure head of 2 bar (30 psig) requires 4.1 bar (60 psig) and 2.0 Nm³/h (1.2 scfm) air consumption. (See dot on chart.)

Caution: Do not exceed 8.6 bar (125 psig) air supply pressure.



Flow rates indicated on chart were determined by pumping water.

For optimum life and performance, pumps should be specified so that daily operation parameters will fall in the center of the pump's performance curve.

9



Performance

NPF07 POLY CLAMPED PTFE-FITTED


Est. Ship Weight.... Polypropylene 1.4 kg (3 lb)

| Air Inlet | 3 mm (1/8") |
|-------------------------------|--------------------|
| Inlet | 6 mm (1/4") |
| Outlet | 6 mm (1/4") |
| Suction Lift | 2.44 m Dry (8') |
| | 8.84 m Wet (29') |
| Disp. Per Stroke ¹ | 0.02 L (0.005 gal) |
| Max. Flow Rate | 18.1 lpm (4.8 gpm) |
| Max. Size Solids | 0.4 mm (1/64") |

¹Displacement per stroke was calculated at 4.8 bar (70 psig) air inlet pressure against a 2 bar (30 psig) head pressure.

Example: To pump 8.7 lpm (2.3 gpm) against a discharge pressure head of 2 bar (30 psig) requires 4.1 bar (60 psig) and 2.4 Nm³/h (1.4 scfm) air consumption. (See dot on chart.)

Caution: Do not exceed 8.6 bar (125 psig) air supply press.




Flow rates indicated on chart were determined by pumping water.

For optimum life and performance, pumps should be specified so that daily operation parameters will fall in the center of the pump's performance curve.

Tel: 866-777-6060 Fax: 866-777-6383

Exploded View





Parts Listing

NPF07 RUBBER-TPE FITTED

| No. | Part Description | Qty. | Part # |
|-----|--|------|-----------------|
| 1 | PWR-FLO® Air Valve Assembly | 1 | N00-2000-20-700 |
| 2 | PWR-FLO [®] Air Valve End Cap | 1 | N00-2300-20-700 |
| 3 | End Cap O-Ring (-017) | 1 | N00-2390-52-700 |
| 4 | Muffler Element | 1 | N00-3240-26-700 |
| 5 | Air Valve Bolt | 4 | N00-6000-03-700 |
| 6 | Air Valve Gasket | 1 | N00-2600-52-700 |
| 7 | Air Valve Nut | 4 | N01-6400-03 |
| 8 | PWR-FLO® Center Section | 1 | N00-3150-20-700 |
| 9 | Pilot Spool Assembly | 1 | N00-3850-99-700 |
| 10 | Pilot Spool Retaining Ring | 1 | N00-2650-03-700 |
| 11 | Shaft | 1 | N00-3800-99-700 |
| 12 | Disc Spring | 2 | N00-6800-08 |
| 13 | Inner Piston for Rubber/TPE | 2 | N00-3700-20-700 |
| 14 | Outer Piston | 2 | N00-4570-20 |
| 15 | Liquid Chamber | 2 | N00-5001-20 |
| 16 | Manifold Tee Section | 2 | N00-5160-20 |
| 17 | Top Retainer | 2 | N00-5411-20 |
| 18 | Bottom Retainer | 2 | N00-5420-20 |
| 19 | Valve Seat | 4 | N00-1130-20 |
| 20 | Valve Seat O-Ring* | 4 | N00-1200-58 |
| 21 | Combo Retainer O-Ring* | 4 | N00-1260-58 |
| 22 | Valve Ball | 4 | N00-1080-55 |
| 23 | Tee Section O-Ring* | 4 | N00-1300-58 |
| 24 | Diaphragm* | 2 | N00-1010-58 |
| 25 | Clamp Band Assembly | 2 | N00-7300-03 |
| 26 | - Clamp Band Bolt | 4 | N01-6100-03 |
| 27 | - Clamp Band Nut | 4 | N01-6400-03 |

^{*}See Elastomer Options


¹Air Valve Assembly includes items 2, 3, and 4

Exploded View



NPF07 PTFE FITTED

Fax: 866-777-6383





Parts Listing

NPF07 PTFE FITTED

| No. | Part Description | Qty. | Part # |
|-----|--|------|-----------------|
| 1 | PWR-FLO® Air Valve Assembly | 1 | N00-2000-20-700 |
| 2 | PWR-FLO [®] Air Valve End Cap | 1 | N00-2300-20-700 |
| 3 | End Cap O-Ring | 1 | N00-2390-52-700 |
| 4 | Muffler Element | 1 | N00-3240-26-700 |
| 5 | Air Valve Bolt | 4 | N00-6000-03-700 |
| 6 | Air Valve Gasket | 1 | N00-2600-52-700 |
| 7 | Air Valve Nut | 4 | N01-6400-03 |
| 8 | PWR-FLO® Center Section | 1 | N00-3150-20-700 |
| 9 | Pilot Spool Assembly | 1 | N00-3850-99-700 |
| 10 | Pilot Spool Retaining Ring | 1 | N00-2650-03-700 |
| 11 | Shaft | 1 | N00-3800-99-700 |
| 12 | Rubber/TPE | 2 | N00-3700-20-700 |
| 13 | Back Up O-Ring* | 2 | N00-1070-58 |
| 14 | Liquid Chamber | 2 | N00-5001-20 |
| 15 | Manifold Tee Section | 2 | N00-5160-20 |
| 16 | Top Retainer | 2 | N00-5411-20 |
| 17 | Bottom Retainer | 2 | N00-5420-20 |
| 18 | Valve Seat | 4 | N00-1130-20 |
| 19 | Valve Seat O-Ring* | 4 | N00-1206-60 |
| 20 | Combo Retainer O-Ring* | 4 | N01-1205-60 |
| 21 | Valve Ball | 4 | N00-1080-55 |
| 22 | Tee Section O-Ring* | 4 | N00-1300-60 |
| 23 | Diaphragm* | 2 | N00-1030-55 |
| 24 | Clamp Band Assembly | 2 | N00-7300-03 |
| 25 | - Clamp Band Bolt | 4 | N01-6100-03 |
| 26 | - Clamp Band Nut | 4 | N01-6400-03 |

^{*}See Elastomer Options

¹Air Valve Assembly includes items 2, 3, and 4



1645 W. Park Ave., Suite 200 Redlands, CA USA 92373

(909) 798-9532



NO BOUNDARIES_{TM}